

Happijac Wireless Remote Programming Instructions

Use these instructions to establish communication between remote unit and receiver when either are replaced.

Step 1: Remove the access cover from the side of the remote and plug in the coiled telephone cord.

Step 2: Plug the other end of the coiled cord into the receiver.

Step 3: Simultaneously press the ALL UP & ALL DOWN buttons, (buttons 5 and 6). - A green light will appear on the remote.

Step 4: Press button #8 five times, then press button #0 five times.

Step 5: Simultaneously press the ACC IN & OUT buttons. A green light will appear on the receiver.

Step 6: Remove coiled cable and check to see that receiver is responding to the remote in wireless mode.

